



Antenna Mounting Instructions

FHD/F25/FBO

VERIFY:

Lay out the system you intend to install. Check that the antenna you received is the same as the one on the fender.

Note: If vehicle does not have an existing antenna on it, the mounting bracket still exists on the passenger side windshield wiper tray. In that case, please skip the "removal" section and move directly to the "install" section.

INSTALLATION:

Removal:

1. Remove the existing antenna starting with the mast.
2. Remove cowl trim panel. (Windshield wiper tray)
3. Remove sheet metal screws and pull up on base.
4. Disconnect cable and hold (this cable may be used to pull feedline of disguised antenna into cab of the vehicle).
5. If the feedline cable refuses to come into the cabin of the vehicle you may access through wheel well liner. In most cases, the liner can be removed with a few sheet metal screws.
6. If the connector stops the feedline from threading through the firewall, the connector may be snipped off and reinstalled once the feedline is inside the vehicle.

Install:

1. Position antenna mount so that the pattern for the mounting screws line up.
2. Adjust while tightening to insure the base seats correctly.
3. Replace cowl trim panel
4. Thread mast and tighten by hand.

Interconnect:

Refer to the enclosed **Installation Considerations** with respect to connecting cables.

Closure:

It is a good idea to conduct system testing before returning panels and trim moldings to their original positions.

