



OMNI-DB-7-800/PCS

760-890 & 1850-1950 MHz

INSTALLATION:

- 1) INSERT THE ANTENNA MAST THROUGH THE HOLE IN THE MOUNTING BRACKET.
- 2) TIGHTEN THE HEX BOLT ONTO THE ALUMINUM PORTION OF THE MAST
- 3) SLIDE THE ANTENNA AND MOUNTING BRACKET ASSEMBLY OVER THE MOUNTING PIPE AND TIGHTEN THE U-BOLT.

